

Cisco SFP and Port Commands

Dec 2019

I purchased some SFPs to go in to a Cisco 10GB switch, and found they did not work in my switch. While investigating the fault, I found some useful commands to help me.

These commands seem to work on both Cisco IOS and the Nexus switches, albeit with some slightly different syntax.

Show Inventory

Show Inventory - [sh inventory](#) displays information about the switch hardware options:

```
NAME: "Chassis", DESCR: "Nexus 3548 Chassis"
PID: N3K-C3548P-10G      , VID: V02 , SN: F0C1822R0WS

NAME: "Module 1", DESCR: "48x10GE Supervisor"
PID: N3K-C3548P-10G      , VID: V02 , SN: F0C18220S2A

NAME: "Fan 1", DESCR: "Chassis fan module"
PID: NXA-FAN-30CFM-F     , VID: N/A , SN: N/A

NAME: "Fan 2", DESCR: "Chassis fan module"
PID: NXA-FAN-30CFM-F     , VID: N/A , SN: N/A

NAME: "Fan 3", DESCR: "Chassis fan module"
PID: NXA-FAN-30CFM-F     , VID: N/A , SN: N/A

NAME: "Fan 4", DESCR: "Chassis fan module"
PID: NXA-FAN-30CFM-F     , VID: N/A , SN: N/A

NAME: "Power supply 1", DESCR: "AC power supply"
PID: N2200-PAC-400W      , VID: V04 , SN: DTN1817P5GC

NAME: "Power supply 2", DESCR: "AC power supply"
PID: N2200-PAC-400W      , VID: V04 , SN: DTN1817P5Q1
```

Show Interface

Show Interface displays detailed information about each interface. If you only issue the command [sh interface](#) (Nexus) (or [sh interfaces](#) for IOS) then you get information regarding all interfaces.

You can get information on a specific interface by using the Cisco syntax [sh interface ethernet 1/1](#). In this example we get the information for port 1. Depending on your switch you might have to use [ethernet](#) or [GigabitEthernet](#) etc.

```
Ethernet1/1 is up
Dedicated Interface
Hardware: 100/1000/10000/40000 Ethernet, address: 88f0.31ca.b0c8 (bia 88f0.31c
a.b0c8)
MTU 1500 bytes, BW 100000000 Kbit, DLY 10 usec
reliability 255/255, txload 1/255, rxload 1/255
Encapsulation ARPA
Port mode is access
full-duplex, 10 Gb/s, media type is 10G
Beacon is turned off
Input flow-control is off, output flow-control is off
Rate mode is dedicated
Switchport monitor is off
EtherType is 0x8100
Last link flapped 00:14:47
Last clearing of "show interface" counters never
5 interface resets
30 seconds input rate 24 bits/sec, 0 packets/sec
```

```
30 seconds output rate 296 bits/sec, 0 packets/sec
Load-Interval #2: 5 minute (300 seconds)
  input rate 192 bps, 0 pps; output rate 360 bps, 0 pps
RX
  0 unicast packets  115 multicast packets  34 broadcast packets
  149 input packets  22045 bytes
  0 jumbo packets  0 storm suppression bytes
  0 runs  0 giants  0 CRC  0 no buffer
  0 input error  0 short frame  0 overrun  0 underrun  0 ignored
  0 watchdog  0 bad etype drop  0 bad proto drop  0 if down drop
  0 input with dribble  0 input discard
  0 Rx pause
TX
  520 unicast packets  0 multicast packets  0 broadcast packets
  520 output packets  49544 bytes
  0 jumbo packets
  0 output errors  0 collision  0 deferred  0 late collision
  0 lost carrier  0 no carrier  0 babble  0 output discard
  0 Tx pause
```

Show Interface Status

Show Interface Status will display a summary of interfaces and their status. Use either [sh interface status](#) to show all interfaces, or [sh interface ethernet 1/1 status](#) to show specific interface.

Port	Name	Status	Vlan	Duplex	Speed	Type
Eth1/1	--	connected	1	full	10G	Unknown Typ
Eth1/2	--	sfpAbsent	1	full	10G	--
Eth1/3	--	sfpAbsent	1	full	10G	--
Eth1/4	--	sfpAbsent	1	full	10G	--

Show Interface Transceiver Details

Show Interface Transceiver Details gives more specific information about the interface in a port. This is useful for SFPs, not so useful for fixed ethernet interfaces. Use: [sh interface transceiver details](#) .

```
Ethernet1/1
  transceiver is present
  type is Unknown Type-(unknown)
  name is Amphenol
  part number is 603830001
  revision is N
  serial number is APF13350017WFF
  nominal bitrate is 10300 MBit/sec
  Link length supported for copper is 1 m
  cisco id is --
  cisco extended id number is 4

DOM is not supported
```

Show Version

Show Version gives information regarding the hardware, software and BIOS version of the switch. Use: [sh version](#)

```
Cisco Nexus Operating System (NX-OS) Software
TAC support: http://www.cisco.com/tac
Documents: http://www.cisco.com/en/US/products/ps9372/tsd_products_support_series_home.html
Copyright (c) 2002-2014, Cisco Systems, Inc. All rights reserved.
```

The copyrights to certain works contained herein are owned by other third parties and are used and distributed under license. Some parts of this software are covered under the GNU Public License. A copy of the license is available at <http://www.gnu.org/licenses/gpl.html>.

Software

BIOS: version 1.9.0
loader: version N/A
kickstart: version 6.0(2)A1(1d)
system: version 6.0(2)A1(1d)
Power Sequencer Firmware:
Module 1: version v3.1
BIOS compile time: 10/13/2012
kickstart image file is: bootflash:///n3500-uk9-kickstart.6.0.2.A1.1d.bin
kickstart compile time: 1/30/2014 9:00:00 [01/30/2014 18:31:05]
system image file is: bootflash:///n3500-uk9.6.0.2.A1.1d.bin
system compile time: 1/30/2014 9:00:00 [01/30/2014 19:39:25]

Hardware

cisco Nexus 3548 Chassis ("48x10GE Supervisor")
Intel(R) Pentium(R) CPU @ 1.50GHz
with 4117860 kB of memory.
Processor Board ID F0C18220S2A

Device name: switch
bootflash: 2007040 kB

Kernel uptime is 0 day(s), 4 hour(s), 23 minute(s), 57 second(s)

Last reset

Reason: Unknown
System version: 6.0(2)A1(1d)
Service:

plugin

Core Plugin, Ethernet Plugin

Alan Walker 2019/12/02 11:30

From:
<https://wiki.alanwalker.uk/> - WalkerWiki - wiki.alanwalker.uk

Permanent link:
https://wiki.alanwalker.uk/doku.php?id=cisco_sfp_and_port_commands&rev=1575286645

Last update: **2023/03/09 22:35**

