

OnBoard NeoPixel

Jun 2026



Introduction

The RP2040-Zero mini has an onboard NeoPixel. So we cannot use the Raspberry Pi Pico code to use this LED. Instead we need to use some Micro Python specific to the Waveshare (or compatible) device.

The NeoPixel is situated between the Boot and Reset buttons.



From:
<https://wiki.alanwalker.uk/> - WalkerWiki - wiki.alanwalker.uk

Permanent link:
https://wiki.alanwalker.uk/doku.php?id=onboard_neopixel&rev=1784466116

Last update: 2026/07/19 13:01

