

Use gphoto2 to Configure DSLR

Jun 2017

We can control the settings on our DSLR, again what can be controlled will vary between models. To get a list of items that can (maybe) control, you can use this command.

```
gphoto2 --list-config
```

Here is the listing that I get from my Canon EOS 700D.

```
/main/actions/uiunlock
/main/actions/syncdatetime
/main/actions/autofocusdrive
/main/actions/manualfocusdrive
/main/actions/eoszoom
/main/actions/eoszoomposition
/main/actions/eosviewfinder
/main/actions/eosremoterelease
/main/settings/datetime
/main/settings/reviewtime
/main/settings/output
/main/settings/movierecordtarget
/main/settings/ownername
/main/settings/artist
/main/settings/copyright
/main/settings/customfuncex
/main/settings/autopoweroff
/main/settings/capturetarget
/main/settings/capture
/main/status/serialnumber
/main/status/manufacturer
/main/status/cameramodel
/main/status/deviceversion
/main/status/vendorsextension
/main/status/model
/main/status/ptpversion
/main/status/batterylevel
/main/status/lensname
/main/status/eosserialnumber
/main/status/shuttercounter
/main/status/availableshots
/main/imgsettings/imageformat
/main/imgsettings/imageformatsd
/main/imgsettings/iso
/main/imgsettings/whitebalance
/main/imgsettings/colortemperature
/main/imgsettings/whitebalanceadjusta
/main/imgsettings/whitebalanceadjustb
/main/imgsettings/whitebalancexa
/main/imgsettings/whitebalancexb
/main/imgsettings/colospace
/main/capturesettings/autoexposuremode
/main/capturesettings/drivemode
/main/capturesettings/picturestyle
/main/capturesettings/aperture
/main/capturesettings/shutterspeed
/main/capturesettings/bracketmode
/main/other/d402
/main/other/d407
/main/other/d406
/main/other/d303
/main/other/5001
```

So for example, in this list we can see a setting entitled `/main/capturesettings/aperture` which indicates we can control the aperture on this

DSLR.

To see what the possible values for `/main/capturesettings/aperture` that `gphoto2` supports, we can use the following syntax.

```
gphoto2 --get-config /main/capturesettings/aperture
```

The 700D DSLR I am using returns the following:

```
Label: Aperture
Type: RADIO
Current: 4.5
Choice: 0 4.5
Choice: 1 5.6
Choice: 2 6.7
Choice: 3 8
Choice: 4 9.5
Choice: 5 11
Choice: 6 13
Choice: 7 16
Choice: 8 19
Choice: 9 22
```

So we can see that the current aperture is 4.5 (probably due to the lens I am using) and we have a choice to select one of the others, lets try to set the aperture to F11.

We can set the aperture using either the absolute value (11) or the index next to the value (choice 5). Here is an example setting using the absolute value.

```
gphoto2 --set-config-value /main/capturesettings/aperture=11
```

From:
<https://wiki.alanwalker.uk/> - WalkerWiki - wiki.alanwalker.uk

Permanent link:
https://wiki.alanwalker.uk/doku.php?id=use_gphoto2_to_configure_dslr&rev=1498408418

Last update: 2023/03/09 22:35

