Cisco Configuration

Cisco 3560 Configuration Guide for iSIS8000 Systems

Introduction

The following document deals purely with the configuration of 3560 switches used in ISIS8000 systems under nCC V5 control. It covers both TS data and TS output switches.

Cisco switches are becoming more and more common in TANDBERG systems as they are used to interface various products to customer IP networks. The switches can be used in many roles with in the system. The following document is designed to assist setting up Cisco equipment for use with nCompass Control and iSIS8000 systems.

This document gives an overview of all the functions associated with Cisco switches when used with nCompass Control. The document is only to be used as a guide to assist engineers in setting up and configuring switches. The following instructions for setting up switches in the following modes are covered:-

1. TS Data switch
2. TS Output switch

Switch Types

Cisco switches can be used in nCompass Control to carry broadcast traffic over IP. nCompass can currently control specific Cisco switch models for device redundancy. The operation of the switch is controlled by SNMP.

nCompass can currently support the following switches for device control:-

- Cisco 3550/60 Series (3560 for iSIS8000)
- Cisco 4500 Series

There are currently two software versions available on the Cisco 3550/60. There is no difference in hardware between an SMI and EMI switch. The two software versions are Enhanced Multilayer Image (EMI) and Standard Multilayer Image (SMI). EMI provides more features such as enhanced security, Quality of Service (QoS), OSPF Routing and Protocol Independent Multicast (PIM). IP streamer and encoder systems can use an SMI switch unless specified otherwise.

Cisco 2950 switches are used for Management network redundancy only.

Initial Switch Configuration (3560)

The following is intended as a guide to configure Cisco catalyst switches to work with nCompass. If a GigE switch (i.e. Cisco 3560G) is being used the replace all instances of fa0/? With gi0/?

- <R> denotes the Return key.
- Switch> Prompt is the base menu.
- Switch# Prompt is the enable menu (type ‘en’ and password (if one is set) to get to this point from initial prompt). Type end to return to Switch>
- Switch(Config) Prompt is the configure mode. Type ‘conf t’ from enable menu, type ‘end’ to exit to enable menu.
- Switch(Config-IF) Prompt is a typical sub configuration menu. Type int fa0/1 to get to this point type ‘exit’ to return to Switch (Config) or ‘end’ to return to enable menu (Switch#)
- In the enable menu (Switch#) type ‘sh ru’ to view the existing configuration.
- The TAB key can be used to complete words i.e. sw <TAB> will complete to switchport etc.
- The up or down curser can be used to recall earlier commands for that menu. (Hyperterminal may prevent this if not set correctly. This feature will always work with Telnet).
- To cancel a command type ‘no [command]’ <R>.

From:
https://wiki.alanwalker.uk/ - **WalkerWiki - wiki.alanwalker.uk**

Permanent link:
https://wiki.alanwalker.uk/doku.php?id=cisco_configuration_ttl&rev=1474637148

Last update: **2023/03/09 22:35**